

EXCHANGE OF DOUBLE HANDLES

IMPORTANT: FOLLOW THESE INSTRUCTIONS !

Please take a pair of pliers/pincers and destroy the plastic cap (3) on the side marked with the arrow below. Then grasp the metal stick (1) and pull it out. Take off the handle. The metal holder (2) together with the rivets (4) has to be left ! Put now on the new plastic cover and fix the handle by driving the metal stick in.

